

## NextG uSee Remote Monitoring Camera Quick Start Guide

### UNIT INCLUDES

Your uSee Remote Monitoring Camera includes the following parts.

- 1 x NextG uSee Remote Monitoring Camera
- 1 x Antenna
- 1 x Solar Panel (or other power supply)
- 1 x Camera Mounting Bracket
- 1 x Mounting Adaptor Plate
- 3 x M5 Bolts and Nuts
- 3 x 50mm/2" Clamps
- 1 x Spiral Cable Wrap

### CAMERA INSTALLATION

Selecting site:

- Make sure you have mobile reception.
- Ensure the Solar Panel can receive ideally 6 hours of direct sun, with the Camera pointing South and the Solar Panel facing North.
- If monitoring a trough, place the camera between 5-8 meters away to get an overall image.

Installation:

Once you have selected your site, we recommend mounting your camera on a standard 2" pipe. After the pipe has been fitted you will need the following tools to mount your Camera.

- 12mm Spanner for Mounting Clamps
- Spanner for M5 Bolts
- Phillips screwdriver
- Cable ties and heavy-duty tape (recommended)



1. Mount the Solar Panel on the top of the post, facing North using 1 x 2" clamp.
2. Attach the mounting plate on the back of the Camera mount with the three M5 bolts. Ensure that these bolts are tight.
3. Mount the Camera on the post using the clamps supplied.
4. Screw the Antenna into the hole in the Solar Panel bracket. If the Antenna is a directional type (a Yagi), align it now.
5. Connect the Antenna cable to the Camera cable. Tape up the connection to protect it from the weather and dirt.
6. To turn the Camera on, plug the other Camera cable into the Solar Panel.
7. Cover all cables with the spiral wrap
8. Tidy up any loose cables with cable ties/tape and ensure that everything is secure. If using cable ties, we recommend not trimming them as this will help discourage birds from landing and chewing the cables.
9. To check that the Camera has been installed correctly and pointing in the right direction, log onto your uSee Dashboard using the website or app.

### MAINTENANCE

To ensure your unit is working to its full capacity please perform the following maintenance regularly.

- Clean the Solar Panel so the battery can fully charge.
- Clean the front of the Camera with a soft cloth so images are clear.
- Inspect all cables for any possible damage or chew marks from birds.
- Ensure the unit and mount are secure and won't move in any unpredictable weather.

- Check your Site Information regularly on the uSee Dashboard to make sure the Battery, Solar Panel and Signal are adequate.

## USEE DASHBOARD

You can access your uSee Dashboard via [www.usee.com.au](http://www.usee.com.au) or by downloading the app onto your IOS or Android mobile device. Create your account by clicking on "Get Started", enter your details and click "Register".

Activate your Site:

- Web browser on a computer – click "Your Name", "Activate Site" and enter the activation code supplied at the start.
- App on mobile device – tap "Settings", "Activate" and then scan the QR Code supplied at the start.

Get Daily Email with notifications about your site/s:


- Web browser on a computer - click "Your Name", "Notification Contacts" in the grey menu on the left-hand side and create your contact.

Edit Photo Schedule:

- Web browser on a computer - hover over the sites Settings Cog and click "Edit Schedule"
- App on mobile device – tap "Settings", tap on the site you wish to edit and then "Edit Schedule"

Set up site notifications e.g. battery levels and scheduled photos:

- Web browser on a computer – hover over the sites Settings Cog and click "Notifications".



## CREDIT

Your sites data usage is pre-paid and requires credit to be applied. Your credit will allow you to schedule up to 10 photos per day. *Your site comes with 1 month's free credit upon activation.* You will receive an email and notification when you login to your dashboard letting you know when your site is about to run out of credit. Once a site runs out of credit it will deactivate and won't record any data. To add credit:

- Web browser on a computer - click "Your Name", "Prepaid Site Credit" and "Add Credit" onto the site you want to add credit to.

## WARRANTY

All our uSee units are covered by a return to base, 12-month warranty. Our warranty only covers manufacturing faults and not wear and tear or any damage caused to the unit. We are unable to offer any warranty on the unit's battery if the recommended maintenance is not performed.

## BATTERY

The battery in your uSee unit has a limited life due to their exposure to the outside elements. They will need to be replaced once every 12 months to ensure your unit performs correctly.

NextG uSee Remote Monitoring Camera Battery: 6v, 4.5Ah Sealed Lead-Acid Battery

## SUPPORT

Please don't hesitate to contact us if you need any help with your unit, have any questions or queries. You can contact us:

Phone: 1300 485 629, Monday to Friday, 8:30am – 5:00pm, Saturday 9:00am – 12:00pm

Email: [support@harringtonsystems.com.au](mailto:support@harringtonsystems.com.au)

Website: [www.harringtonsystems.com.au](http://www.harringtonsystems.com.au) and [www.usee.com.au](http://www.usee.com.au)

Address: Harrington Systems Electronics, 623 Olga Downs Rd, Richmond, 4822